



SLUSHY MACHINE HIRE

Please allow at least 1 hr to slushy



SETUP OF MACHINE

- 1 Insert tap make sure you use a little bit of soapy water on tap to lubricate so tap move freely failure to do this will make tap hard to push and will break.
- 2 Make sure once tap install seal is still in its groove if not remove and repeat first step or tap will leak
- 3 Pour water in fist to make sure there is no leaks and then mix. please refer to label on slushy mix. For right ratio.
- 4 Make sure all switched are set to slushy on side of machine and you are ready to go.



Cleaning machine

Remove tap and clean with only warm soapy water DO NOT used a scrubbing brush etc as this will scratch slushy bowl. Thankyou

PLESES MAKE SURE MACHINE IS CLENED ON RETURN OR CLENING FEE WILL BE CHARRD



Slushy parts

SIZE OF MACHINE IS: H 930 W540 D 500