

DANCE FLOOR INSTRUCTIONS

FOR SELF INSTALL YOU WILL NEED A SCREW GUN YOU CAN HIRE ONE

DANCE FLOOR SIZES: 4.8 x 3.6 / 4.8 x 4.8 / 4.8 x 6.0 / 4.8 x 7.2



1. Join long 3.0m timber and short 1.8m timber together no need to screw.(Picture on left side)



2. Lay the timber pieces down so the middle one picks up centre screw holes.

3. Make sure when you lay boards down that the 3rd timber is only half

underneath board (like in the picture above), so next board can go hard up next to it and continue, depending on the dance floor size.



4. Screw boards down as you go AND make sure metal holes are facing to the top. ONLY PUT SCREW IN METAL PRE-DRILLED HOLES.

PLEASE DO NOT PUT NEW HOLES IN BOARDS

NOTE: DO NOT LIFT BOARDS UP WHEN TAKING DANCE FLOOR APART UNTILL YOU UNSCREW IT FRIST. AS THIS WILL BREAK CORNERS OUT AND WE WILL CHARGE YOU FOR REPLACEMENT OF NEW BOARD.

(Any queries please call our office 02 6721 4495 or A/H 0408 222 290)