


# **INSTRUCTIONS FOR SELF ERECTION OF MARQUEE**

1. Spread roof of marquee on the ground in desired position. Making sure laced section are facing each other and pulling corners out taut. 24ft x24 ft has only end sections; add one mid sections for 24ft x 36ft and 2 mid sections for 24ft x 48ft
2. Stitch roof together, after place flap over and stitch up. Make sure long rope hangs under roof for later. Than pulling corners out taut.
3. Install pegs in line with pole holes in roof, approx. 3ft from edge of roof line. 2 pegs at each corner.
4. Install 4 corner poles with the base plate. Run rope through peg and back through metal ring and tie off loosely.
5. Install all intermediate poles and tie off loosely. IF SIDE ROPES ARE TOO TIGHT, IT WILL BE HARD TO LIFT THE CENTRE POLE INTO PLACE.
6. Join centre pole together Install centre pole/s make sure spike is through both roofs and then lift pole. Tie rope hanging from roof off through pole stopping roof from lifting and causing damage to roofs.
7. Straight outer poles and tie off securely.
8. Install walls. (If Desired) Starting at corner and continue around the marquee, fixing to poles and lacing together as you go. Walls can be folded back at joins to form doorways. *(Any queries please call office 02 6721 4495 or A/H 0408 222 290)*



**\* IF MARQUEE RETURNED DAMAGED; DIRTY OR WET AND NOT PUT AWAY NEATLY YOU WILL BE CHARGED\***